



CABLE SHEATH REPAIRS

SCOPE

This procedure is only to be used for cable sheath repairs when the sheath has been nicked, has shallow cuts or scratches or has abrasion damage.

Do not use this procedure for cable sheath repairs where the sheath is cut right through.

This procedure uses a “Raychem”, Type CRSM, Wraparound Heatshrinkable Cable Repair Sleeve. When ordering the repair sleeve, request an instruction sheet from the supplier.

REPAIR

1. Apply the repair sleeve when the cable is straightened and in its final position.
2. Clean, degrease and abraided the sheath for 100 mm each side of the damage area.
3. Follow the Raychem instructions for installation of the repair sleeve.